


# THE COOLING SYSTEM COMPONENTS

## ALL ABOUT COOLANT PUMP



### THE COOLING SYSTEM – INTERNAL COMPONENTS:

- 1 Coolant Pump
- 2 Cylinder Liners
- 3 Oil Cooler Flanges
- 4 Coolant Channels
- 5 Cylinder Liner Cooling Jackets
- 6 Thermostat
- 7 Coolant Duct
- 8 Air Compressor

The largest amount of coolant is routed up through the oil cooler flanges **3** and is distributed via channels **4** to the upper part of the cylinder liner cooling jackets, while a smaller fraction is diverted to the lower part of the liners via holes **2**. From the liner cooling jackets the coolant flows through channels **5** up to the cylinder head, cooling the hot areas surrounding the exhaust ports and injector copper sleeves and finally reaches the thermostat **6**.

The thermostat is located where the fluid leaves the engine. When the coolant is cold the thermostat is closed, directing the coolant directly back to the suction side of the pump, via a duct **7**, to shorten the engine warm-up time. When the engine reaches operating temperature and the thermostat starts to open, the duct to the coolant pump gradually closes and at the same time opens up for the coolant to flow through the radiator. Above a certain coolant temperature all coolant is directed via the radiator.

The air compressor **8** is cooled via a separate external cooling circuit.

### THE COOLING SYSTEM – EXTERNAL COMPONENTS:

- 1 + 2 Overflow Tubes
- 3 Filling Cap
- 4 Expansion Tank
- 5 Level Indicator
- 6 Coolant Hose
- 7 Cab Heater/Heat Exchanger
- 8 Coolant Pump

When the fluid in the cooling system heats up, it expands, causing some of the coolant to flow through the overflow tube **1** on top of the radiator into the bottom of the expansion tank **4**. If there is air in the system it will be evacuated via tubes **1** and **2** into the expansion tank.


When the coolant cools back down, a vacuum is created, sucking water back in from the bottom of the expansion tank via hose **6** to replace the water that was expelled.

The vacuum then created in the expansion tank is evened out via a breather valve located in the expansion tank filling cap **3**.

This valve is a dual function valve also acting as a pressure limiting valve, which determines the maximum pressure in the cooling system. In the expansion tank there is also a level indicator **5** connected to a warning lamp on the dashboard.

There is a separate circuit for the cab heating system.

Coolant from the cylinder head is routed through a heater cell package **7** and is then returned back to the coolant pump **8**.



## PRACTICAL ADVICE

### MAXIMISE THE SALE

Don't just sell the coolant pump – look for further opportunities to maximise the sale:

- Does the coolant pump drive belt need replacing.
- Does the coolant pump belt tensioner need replacing.
- Don't forget you will need the latest specification of Renault Trucks coolant pump.

### RENAULT FITTED-PART

- One year warranty.
- Fitted by Renault Trucks trained technicians.

### RENAULT TRUCKS 24/7

- Professional roadside assistance 24 hrs a day, 7 days a week, 365 days a year.
- Dedicated to getting customers' trucks back on the road with minimum delay.



renault-trucks.com

Renault Trucks SAS with a capital of 50 000 000 € - 954 506 077 RCS Lyon Crédit photos : © Renault Trucks - 01/2017



renault-trucks.com



# FACT

## Avoid the increased risk of premature engine component wear as a result of excessive overheating.

If your coolant pump is not working properly there is a risk that the coolant temperature will rise, which will result in a higher activation of the cooling fan more often, leading to higher fuel consumption. You also risk the engine losing power and, indirectly, increased wear on engine components.

## THE DIAMOND DISTINCTION

### 1 | The Renault Trucks dimensions

The efficient design of the pump impeller and flow chambers in the Renault Trucks coolant pump results in lower fuel consumption and contributes to maximum engine output.

### 2 | Material specification

The impeller is made of non-metallic (ceramic) material which makes it lighter and less susceptible to cavitation damage.

### 3 | Designed as one

Developed together with the Renault Trucks engine to build up the correct pressure in the cooling system to provide the right coolant circulation to achieve optimum cooling performance.



As the heart of the cooling system, a GENUINE Renault Trucks coolant pump is key to ensuring an operator's engine is always running at the correct temperature, minimising the indirect increase of premature wear on engine components and delivering long-life performance and up time.

FEATURES	BENEFITS
The coolant pump performance is developed and tested together with the Renault Trucks's complete coolant system.	
Provides the correct flow of coolant to all components in the system.	Optimises the engine reliability, durability and cab comfort.
Impeller in non metallic material minimises the cavitation risks.	Extend the coolant pump lifetime which increases the vehicle uptime.
Extensive tests of the complete system including all components over years to secure a premium durability coolant system.	Optimise the operation performance and lower the total operating lifetime costs.
Dual Stage Clutch: D11C, D13C, D16G.	Improved fuel efficiency.

## TWO PARTS MAY LOOK ALIKE, BUT...

There will always be non-genuine suppliers wanting to sell coolant pumps to Renault trucks operators. The quality of these non-genuine makes naturally varies as much as their prices.

However, even if a well-known non-genuine Renault Trucks make is chosen – it is by no means certain that the coolant pump is tailored and to the specification of a Renault Trucks cooling system in the same way as a GENUINE Renault Trucks part.

### DEVELOPED IN HARMONISATION

All of the component parts of a Renault Trucks cooling system have been developed together as a complete system so as to create the necessary flawless interplay between them – to ensure the maximum performance and service life from the cooling system and the engine components.

### EXTENSIVE TESTING

Renault Trucks develops, tests and verifies the cooling system as a complete system – not as individual components. The Renault Trucks cooling system is a complete system, with each component subjected to thousands of hours of demanding performance testing. Tests are carried out on every component, and then finally the complete cooling system is field tested in extreme road and weather conditions. These tests are undertaken to achieve an exact balance between components, to give a Renault Trucks engine the maximum efficiency and performance. In addition Renault Trucks's GENUINE coolant pumps are approved by Renault's extensive quality assurance process.

### INCREASED DEMANDS

Increased engine performance demands more efficient cooling. This puts much higher stress on the coolant pump and its components. As a result increased demands are placed on the interaction between the different components of the cooling system



Renault Trucks specifies precise requirements on each component and those that cannot be remanufactured to that standard are replaced with new components. This ensures that a Renault Trucks eXchange coolant pump meets the same technical specifications as a brand new one.

Renault Trucks eXchange coolant pump offers the exact same performance and lifetime as an original GENUINE Renault Trucks coolant pump. In addition, the eXchange coolant pump also carries exactly the same warranty as a brand-new unit.

### RISKS OF FITTING NON GENUINE



If a coolant pump is not working properly, it does not build up the correct coolant pressure or provide the correct coolant circulation, leading to the following consequences:

- Indirectly increased wear on engine components.
- Cavitation damage to the cooling system components, including engine parts in contact with the coolant, due to incorrect pressure in the system – leading to consequential damage.
- Increased fuel consumption due to the cooling fan cutting in more often is a consequence of too high a coolant temperature as a result of poor coolant circulation in the cooling system.
- De-rating of the engines performance – a safety precaution that the engine control unit carries out when the coolant pump is not providing the correct circulation volume leading to the coolant overheating.
- A roadside breakdown as a direct result from a pump system failure:
  - where a bearing in the coolant pump has seized – as a result coolant no longer circulating in the cooling system,
  - the impeller moves on the shaft and finally comes into contact with the pump housing – resulting in either a pump failure or a failure of the belt transmission.

### OPERATING CONDITIONS

The coolant pump operates in conditions of extreme temperature (up to 110°C and down to less than -50°C) and extreme pressure (0.5 Bar inlet pressure and up to 5 Bar outlet pressure). It operates in harmony at twice the speed of the engine. This puts very high demands on the choice of material and the technical specifications.

### IMPELLER

The choice of non metallic material allows for a light impeller, which is not sensitive to cavitation (as aluminium for example). Benchmarking shows that other competitors use a cast iron or brass impeller. The reinforced impeller hub extends the lifetime of the cooling pump.

### WHY GENUINE RENAULT TRUCKS PARTS FOR YOUR COOLING SYSTEM?

- To ensure a reliable and durable cooling system.
- Maximum engine power and optimum emission levels, in both hot and cold climates.
- Long service intervals and low maintenance costs.

✓ **By choosing a GENUINE Renault Trucks coolant pump, you are sure to reach the performance requirements that Renault Trucks has specified for a complete cooling system in a Renault Trucks vehicle.**

# THE COOLING SYSTEM HOW IT WORKS

- A great deal of the energy that is generated during combustion is converted to heat. Some of this heat must be conducted away from the engine to prevent it from overheating – this is the task of the cooling system.
- Modern powerful engines place very high demands on the cooling system, which with the help of coolant; its main purpose is to cool the engine, maintaining the correct temperature for maximum engine power and optimum emission levels. In turn, this prevents increased fuel consumption, loss of engine power and indirect and premature wear on engine components and the lubricating oil.
- The cooling system also ensures that the temperature in the cab is kept at a comfortable level. It is therefore very important that all the cooling system components are calibrated for optimised performance.

## PISTON TYPE THERMOSTAT

The thermostat regulates the flow of coolant through the radiator to provide the right operating temperature for the engine. It allows high coolant flow, with relatively low pressure drop. The piston-type thermostat has a probe, sensing the coolant temperature. The probe is filled with a thermo-reactive wax. When the wax melts, its volume expands acting on a pushrod-piston assembly.

### 1 | Engine Cold

The thermostat piston is completely shut. All coolant is routed back to the suction side of the pump, as shown in the picture to the left.

### 2 | Warm-up Phase

The thermostat piston is in an intermediate position between shut and fully opened, determined by the coolant temperature. The amount of coolant routed to the radiator is then gradually increased with increased coolant temperature, until the engine is warm and the piston is in fully open position.

### 3 | Engine Warm

The thermostat piston is fully opened. All coolant is routed to the radiator, as shown in the picture to the right.

## CAB HEATER/ HEAT EXCHANGER

- The purpose of the heat exchanger is to transfer heat from the hot coolant in the engine's cooling system to the air in the cab. The heat exchanger consists of a number of elements through which coolant from the engine flows. On the outside, the elements are fitted with flanges that emit heat to the passing air.
- A heat control valve is operated by the heater controls on the instrument panel. The valve regulates the flow of coolant through the heat exchanger, thereby regulating the temperature of the heated air. In addition to the heat control valve, trucks fitted with automatic temperature control also have a solenoid valve connected to the coolant hose leading to the heat exchanger. The solenoid valve is electrically controlled by the climate control system's control module. By opening and closing the flow to the heat exchanger, the temperature in the cab is regulated.

## COOLING FAN

- Sometimes the flow of air against the vehicle is not sufficiently powerful to ensure adequate flow through the radiator, so an additional element of the cooling system and equally as important is the cooling fan and its corresponding belt drive which increases the flow of air in the following circumstances:
  - when the vehicle is driving at low speed or is at a standstill with the engine running,
  - when the engine is under a severe load and extra amounts of heat has to be dissipated,
  - hot climates – when the surrounding air is hot and offers poor cooling.
- The cooling fan is driven via a poly-v belt which in turn is driven by the timing gears. This same drive mechanism also drives the alternator and the air conditioning pump.
- The belt system is being driven as long as the engine is running, whilst the fan itself is only driven when a silicon fluid is released into the fans drive coupling.

- The release of such silicon fluid is controlled via the engine management system – in the past this would have been controlled by a temperature sensitive bi-metallic strip on earlier engines.

## RADIATOR

- The radiator is a heat exchanger in which heat is transferred to the surrounding air. The purpose of the radiator is to reduce the temperature of the coolant circulating within the engine and the climate system.
- The radiator consists of two containers, the upper tank and the lower tank, today mostly manufactured of plastic, with a honeycomb mesh between, connecting these two tanks.
- After leaving the engine the coolant enters the upper tank and is then distributed through a tubular system consisting of a multitude of narrow tubes through which the air passes. On the outside of the tubular system there is a series of thin steel fins (honeycomb mesh) which increases the surface contact area with the slipstream of air, and thus enhance the cooling effect. After the coolant has been cooled it enters the lower tank and is then recirculated by the coolant pump to return to the engine once again.

## COOLANT PUMP

- The coolant pump builds up the correct pressure in the cooling system and provides the right coolant circulation to achieve optimum cooling performance.
- The back of the coolant pump with its ducts for the distribution of coolant is machined directly into the cylinder block. The front (external) section comprises an aluminium housing containing a nonmetallic (ceramic material) impeller, shaft seals, bearings and pulley. The bearing is a permanently lubricated combined roller and ball bearing. Between the shaft seals and the bearing there is a ventilated space, which leads into a duct behind the pulley.
- When the impeller (attached to the drive shaft) begins to rotate the pump inducts coolant from the radiator. The coolant enters the pump in the centre of the impeller and then with the aid of centrifugal force is pressed against the walls of the aluminium housing where the outlet is situated.
- The coolant then leaves the coolant pump and circulates around the engine before it returns to the radiator.
- To aid fuel consumption on the modern truck technology on the D11C, D13C and D16G the coolant pump now has an electronically controlled internal clutch. This is a dual stage clutch controlled by the engine ECU via a signal from the engine coolant temperature sensors.
- The first stage controls the temperature to approx. 81°C degrees and then once the engine is producing maximum torque for prolonged periods of time the second stage is engaged to regulate the temperature of the coolant and to increase the coolant flow through the engine and radiator. Once the coolant has reduced back to below 81°C degrees the second stage is then disengaged. The purpose of this is to reduce the amount of friction consumed when the coolant pump is controlled therefore improving the fuel consumption potential of the engine.